

PromptMeGood — Safe UI Enhancement Command for Replit

Paste this entire block into Replit AI.

CRITICAL RULES — READ BEFORE BUILDING ANYTHING

1. **Do NOT replace or modify the cv2-39 pill+drawer pattern.** The existing bottom pill and slim drawer stay exactly as they are. We are only enhancing what is already there.
2. **The correct textarea ID is `#goal` — not `#guided-q-goal`.** That ID was inside the deleted Help Me Start modal.
3. **Do NOT move the Photography Suite out of Visual Studio.** It stays where it is. We are only adding a shortcut button inside the drawer that opens the existing Visual Studio modal.
4. **Do NOT modify any generation logic, API calls, localStorage keys, or backend functionality.** This is a UI-only change.
5. **Make each change as a targeted addition** — do not refactor surrounding code.

Change 1 — Add a ⚡ Quick Generate Button Next to the Existing Pill

The cv2-39 pill at the bottom of the screen is the entry point. Keep it exactly as it is. Add a single ⚡ Quick Generate button sitting to the right of it.

Behavior:

- Tapping ⚡ fires the existing generate function immediately, skipping the drawer entirely.
- Tapping the existing pill opens the cv2-39 drawer as it does today.

HTML

```
<!-- Add this button immediately after the existing cv2-39 pill element -->
<button id="pmg-quick-generate" class="pmg-btn-quick" title="Quick Generate — s
⚡
</button>
```

CSS

```

.pmg-btn-quick {
  width: 44px;
  height: 44px;
  border-radius: 12px;
  border: 1px solid var(--pmg-border);
  background: var(--pmg-input-bg);
  font-size: 20px;
  cursor: pointer;
  display: inline-flex;
  align-items: center;
  justify-content: center;
  flex-shrink: 0;
  transition: background 0.15s ease;
}

.pmg-btn-quick:hover,
.pmg-btn-quick:active {
  background: var(--pmg-border);
}

```

JavaScript

```

// ⚡ Quick Generate – fires existing generate function directly
document.getElementById('pmg-quick-generate').addEventListener('click', () => {
  // Replace 'generatePrompt()' with the actual name of your existing generate
  generatePrompt();
});

```

Change 2 — Add Three Collapsible Sections Inside the Existing cv2-39 Drawer

Inside the existing cv2-39 slim drawer (the one that opens when the user taps the pill), add three collapsible accordion sections. Do NOT rebuild the drawer — only add these sections inside the existing drawer's content area.

The three sections:

Section	Default State on Workstation Tab	Default State on Visual Tab
⚡ Quick Picks (Tone, Category, Goal)	Open	Closed

 Prompt Tuning (Format, Length, Language, etc.)	Closed	Closed
 Photography Suite	Closed	Open

Context-aware default: Check which tab is active when the drawer opens. If `body` has class `pmg-tab-workstation` (or equivalent), open Quick Picks by default. If `body` has class `pmg-tab-visual` (or equivalent), open Photography Suite by default.

HTML

```
<!-- Add this accordion structure inside the existing cv2-39 drawer content area -->
<div class="pmg-accordion">

  <!-- Section 1: Quick Picks -->
  <div class="pmg-acc-section" id="acc-quick-picks">
    <button class="pmg-acc-toggle">
      <span>⚡ Quick Picks</span>
      <span class="pmg-acc-chevron">▾</span>
    </button>
    <div class="pmg-acc-body">
      <!-- Move existing Tone pills here – do not recreate -->
      <div class="pmg-tune-row">
        <label class="pmg-tune-label">Tone</label>
        <div class="pill-group" id="acc-tone-pills"></div>
      </div>
      <!-- Move existing Category/Platform pills here -->
      <div class="pmg-tune-row">
        <label class="pmg-tune-label">Category</label>
        <div class="pill-group" id="acc-category-pills"></div>
      </div>
      <!-- Move existing Goal/Purpose pills here -->
      <div class="pmg-tune-row">
        <label class="pmg-tune-label">Goal</label>
        <div class="pill-group" id="acc-goal-pills"></div>
      </div>
    </div>
  </div>

  <!-- Section 2: Prompt Tuning -->
  <div class="pmg-acc-section" id="acc-prompt-tuning">
    <button class="pmg-acc-toggle">
      <span>🖋️ Prompt Tuning</span>
      <span class="pmg-acc-chevron">▾</span>
    </button>
    <div class="pmg-acc-body">
```

```

    <!-- Move ALL existing prompt tuning controls here -->
    <!-- Format, Length, Language, Personality, Experience Level -->
    <!-- Do not recreate – move the existing DOM nodes -->
  </div>
</div>

<!-- Section 3: Photography Suite (opens Visual Studio modal) -->
<div class="pmg-acc-section" id="acc-photo-suite">
  <button class="pmg-acc-toggle">
    <span>📷 Photography Suite</span>
    <span class="pmg-acc-chevron">▼</span>
  </button>
  <div class="pmg-acc-body">
    <!-- Do NOT move Photography Suite controls here -->
    <!-- Instead show a button that opens the existing Visual Studio modal -->
    <p class="pmg-acc-note">Shape your image with professional camera settings</p>
    <button id="pmg-open-visual-studio" class="pmg-btn-open-visual">
      📷 Open Photography Suite
    </button>
  </div>
</div>

</div><!-- end .pmg-accordion -->

```

CSS

```

/* Accordion wrapper */
.pmg-accordion {
  display: flex;
  flex-direction: column;
  gap: 6px;
  padding: 8px 0;
}

/* Each section */
.pmg-acc-section {
  border: 1px solid var(--pmg-border);
  border-radius: 10px;
  overflow: hidden;
}

/* Toggle button */
.pmg-acc-toggle {
  width: 100%;
  display: flex;
  justify-content: space-between;
  align-items: center;
}

```

```
padding: 12px 14px;
background: var(--pmg-input-bg);
border: none;
color: var(--pmg-text);
font-size: 14px;
font-weight: 600;
cursor: pointer;
text-align: left;
}

/* Collapsed body – hidden by default */
.pmg-acc-body {
  display: none;
  padding: 12px 14px;
  flex-direction: column;
  gap: 12px;
}

/* Open state */
.pmg-acc-section.open .pmg-acc-body {
  display: flex;
}

.pmg-acc-chevron {
  transition: transform 0.2s ease;
  font-size: 12px;
}

.pmg-acc-section.open .pmg-acc-chevron {
  transform: rotate(180deg);
}

/* Tune row */
.pmg-tune-row {
  display: flex;
  flex-direction: column;
  gap: 6px;
}

.pmg-tune-label {
  font-size: 11px;
  font-weight: 700;
  color: var(--pmg-text-muted);
  text-transform: uppercase;
  letter-spacing: 0.06em;
}

/* Open Visual Studio button */
```

```

.pmg-btn-open-visual {
  width: 100%;
  padding: 12px;
  background: var(--pmg-accent);
  color: #fff;
  border: none;
  border-radius: 10px;
  font-size: 14px;
  font-weight: 600;
  cursor: pointer;
}

.pmg-acc-note {
  font-size: 13px;
  color: var(--pmg-text-muted);
  margin: 0;
}

```

JavaScript

```

// Accordion toggle logic
document.querySelectorAll('.pmg-acc-toggle').forEach(toggle => {
  toggle.addEventListener('click', () => {
    const section = toggle.closest('.pmg-acc-section');
    section.classList.toggle('open');
  });
});

// Context-aware default: open correct section based on active tab
function openDrawerWithContext() {
  const isVisualTab = document.body.classList.contains('pmg-tab-visual');
  // Replace class names with whatever your actual tab classes are
  if (isVisualTab) {
    document.getElementById('acc-photo-suite').classList.add('open');
  } else {
    document.getElementById('acc-quick-picks').classList.add('open');
  }
}

// Call this when the cv2-39 drawer opens
// Hook into the existing drawer open event/function

// Open Visual Studio modal from inside the drawer
document.getElementById('pmg-open-visual-studio').addEventListener('click', () => {
  // Replace with the actual function or trigger that opens your Visual Studio

```

```
openVisualStudio();
});
```

Change 3 — Two-Box Output Layout (Generated Prompt + AI Response)

The Layout Rules:

- **Mobile (up to 767px):** Box 1 stacked on top of Box 2. Full width.
- **Desktop (768px+):** Box 1 and Box 2 side by side, equal width.
- **Box 2 is hidden by default.** It only appears after the user clicks "Run with AI."
- **Box 1 remains an editable textarea** exactly as it is today.
- **Box 2 is read-only** and streams the AI response word by word.

Box 1 — The Generated Prompt (Existing, Keep As-Is)

The existing generated prompt output box stays exactly as it is. It is already an editable textarea. Do not change it. Only wrap it in the new two-box layout container.

Box 2 — The AI Response (New)

HTML

```
<!-- Wrap the existing generated prompt box AND add Box 2 inside this container -->
<div class="pmg-two-box-layout">

  <!-- Box 1: Existing generated prompt output – do not modify internals -->
  <div class="pmg-box pmg-box-prompt">
    <div class="pmg-box-label">📝 Your Generated Prompt</div>
    <!-- The existing generated prompt textarea goes here – do not recreate, wrap -->
  </div>

  <!-- Box 2: AI Response – hidden until Run with AI is clicked -->
  <div class="pmg-box pmg-box-response" id="pmg-ai-response-box" style="display:none">
    <div class="pmg-box-label">✨ AI Response</div>
    <div class="pmg-response-content" id="pmg-ai-response-content">
      <!-- AI response streams in here -->
    </div>
  </div>

</div>
```

CSS

```
/* Two-box container */
.pmg-two-box-layout {
  display: flex;
  flex-direction: column; /* stacked on mobile */
  gap: 16px;
  width: 100%;
}

/* Side by side on desktop */
@media (min-width: 768px) {
  .pmg-two-box-layout {
    flex-direction: row;
    align-items: flex-start;
  }
  .pmg-box {
    flex: 1;
  }
}

/* Individual box */
.pmg-box {
  display: flex;
  flex-direction: column;
  gap: 10px;
  background: var(--pmg-panel-bg);
  border: 1px solid var(--pmg-border);
  border-radius: 14px;
  padding: 16px;
}

/* Box label */
.pmg-box-label {
  font-size: 12px;
  font-weight: 700;
  color: var(--pmg-text-muted);
  text-transform: uppercase;
  letter-spacing: 0.06em;
}

/* AI Response content area */
.pmg-response-content {
  font-size: 15px;
  line-height: 1.6;
  color: var(--pmg-text);
  min-height: 120px;
  white-space: pre-wrap;
```



```

overflow-y: auto;
max-height: 400px;
}

/* Fade-in animation for Box 2 */
@keyframes pmg-fade-in {
  from { opacity: 0; transform: translateY(8px); }
  to   { opacity: 1; transform: translateY(0); }
}

.pmg-box-response.is-visible {
  animation: pmg-fade-in 0.3s ease forwards;
}

```

JavaScript

```

// When "Run with AI" is clicked:
// 1. Show Box 2 with fade-in
// 2. Stream the AI response into it word by word

async function runWithAI() {
  const responseBox = document.getElementById('pmg-ai-response-box');
  const responseContent = document.getElementById('pmg-ai-response-content');

  // Show Box 2
  responseBox.style.display = 'flex';
  responseBox.classList.add('is-visible');
  responseContent.textContent = ''; // Clear previous response

  // Show loading state
  responseContent.textContent = '⌚ Generating response...';

  // Get the current prompt from Box 1
  const prompt = document.getElementById('goal').value;

  try {
    // Hook into your existing Run with AI API call here
    // Replace the below with your actual streaming API call
    const response = await fetch('/api/run-with-ai', {
      method: 'POST',
      headers: { 'Content-Type': 'application/json' },
      body: JSON.stringify({ prompt })
    });
  });

  // Stream the response word by word
  const reader = response.body.getReader();
  const decoder = new TextDecoder();

```

```

responseContent.textContent = '';

while (true) {
  const { done, value } = await reader.read();
  if (done) break;
  responseContent.textContent += decoder.decode(value);
  // Auto-scroll to bottom of response
  responseContent.scrollTop = responseContent.scrollHeight;
}

} catch (err) {
  responseContent.textContent = 'Something went wrong. Please try again.';
}
}

// Hook runWithAI() into the existing "Run with AI" button click event
// Replace 'pmg-run-with-ai-btn' with the actual ID of your Run with AI button
document.getElementById('pmg-run-with-ai-btn').addEventListener('click', runWit

```

Summary of All Changes

Change	What It Does	Touches cv2-39?
 Quick button	Added next to existing pill. Fires generate immediately.	No
Accordion sections	Added inside existing drawer. Move existing controls.	No — adds to drawer only
Photography Suite section	Button that opens existing Visual Studio modal.	No — no controls moved
Two-box layout	Box 1 (existing, editable). Box 2 (new, hidden until Run with AI).	No
Streaming AI response	Box 2 fades in and streams response on Run with AI click.	No

Acceptance Criteria

1. The cv2-39 pill and drawer work exactly as they did before — nothing broken.

2. ⚡ Quick Generate button sits next to the pill and fires generate without opening the drawer.
3. The drawer now contains three collapsible accordion sections.
4. Quick Picks is open by default on Workstation tab. Photography Suite is open by default on Visual tab.
5. The Photography Suite accordion section shows a button that opens the existing Visual Studio modal — no controls are duplicated or moved.
6. Box 1 (generated prompt) is editable and works as it does today.
7. Box 2 (AI response) is hidden on page load and only appears after "Run with AI" is clicked.
8. Box 2 fades in and streams the AI response word by word.
9. On mobile (up to 767px) the two boxes are stacked vertically.
10. On desktop (768px+) the two boxes are side by side.
11. No generation logic, API calls, or localStorage keys are modified.
12. `#goal` is used as the textarea ID throughout — not `#guided-q-goal` .